




hydraulic design, fundamentals, and diagnosis; September, 2019








Troubleshooting Compu-Spread hydraulic systems



C-S hydraulic troubleshooting: always check the obvious (easy) things first!

- Is there hydraulic fluid in the reservoir? (Do not rely on the sight glass only for visual confirmation.)
- Is the air breather clean? If not, as the hydraulic fluid level lowers and raises due to differential cylinder demand, and changes in fluid temperature, a partial vacuum can be created, hence, not allowing the fluid to flow as per design towards the inlet of the pump.
- Is air entering the system through the inlet line of the pump due to loose 'T'-clamps (or gear clamps, which should not be used) or cracked welds at the coupling or fitting, or an hardened 'o'-ring on the SAE inlet flange or fitting?
- Is the inlet hose collapsed, or partially collapsed, allowing for interrupted fluid flow to the inlet of the pump, causing cavitation, and hence noise?
- Is the inlet hose inner lining no longer adhering to the inside of the hose, causing a check valve (or flapper) effect, hence obstructing the flow of hydraulic fluid from the reservoir to the pump's inlet?










- 3) NPT fittings used
- 4) too many fittings used hence too many joints!
- 5) does the inlet hose match the pump's inlet port?
- 6) how many clamps on the inlet hose?




Rules of Thumb velocities: C-S: A10VO85 inlet line: 2-4 ft/sec pressure lines:10-20 ft/sec nomograph return lines:10-15 ft/sec Fittings builder installed is for 1-1/2" hose! 85 has a max flow rate of 55 USGPM (212 l/min) @ 2500 rpm Vg 85 @ 1000 rpm Vg 85 @ 1700 rpm Vg 85 @ 2500 rpm RECOMMENDED VELO RANGE FOR PRESSURE L In this example then, with an 1-1/2" hose, we would have to limit the engine RPM to 1000 with the pump at max. displacement in order to not damage the pump or at least reducing its operating life.














C-S: A10VO85 & 100 case drain (leakage) line








C-S: A10VO85 & 100 case drain (leakage) line


- always use as a minimum the same size hose as the leakage line ports (L or L1), using the higher of the two ports, depending on the mounting of the pump. Preferably would be to use the next hose size up, in order to reduce case pressure, especially in high dynamic situations and cold weather which increases the fluid's viscosity.
- always pre-fill the housing with the same hydraulic fluid as the system will be using prior to start-up in order to lubricate the bearings, shaft seal, and other moving parts
- remember that there is no direct communication between the inlet (blue) and the housing, or case (green) of the pump (which is acting as a mini-reservoir)







- we have two (2x) single acting cylinders
- we have two sequence valves
- we have a flow control valve in the form of a fixed orifice
- we have an hydraulic stroke limiter on the stroking piston which ensures a certain quantity of exchange fluid when the pump is in the near de-stroked position
- we have nine (9x) pistons which have tolerances, which means theoretically, 4-1/2 flow sources
- we have cross-port & internal leakage across the cylinder barrel and distributor plate
- we have dynamic responses which can be as fast as 70 milliseconds which means a very high flow rate for a very short duration of time
- and, we have cold weather! (fluid viscosity)



C-S: A10VO pumps, a real life application review

Steve, please take a photo of the "good pump on shelf" including a photo of the nameplate

regards,

Franklin de Waard DCCA/SLM

Tel. +1 905 714-4838

From: steve <a>@gmail.com>

Sent: August 16,

To: de Waard Franklin (DCCA/SLM) < Franklin.deWaard@boschrexroth.ca>


Subject: Re: 2009 vehicle which can only reach 800 psi


We have a good pump on shelf. Do you think this is same configuration


a you think thin





Which port is the inlet and which is the outlet?




































M4 torque values: Inlet Tie-rods




Using **NO** Loctite® on the tie-rod threads (short thread end goes into inlet), hand tighten such that you can feel the thread and then torque to 10 Nm or 7.5 ft.lb using a torque wrench.



M4 torque values: valve slices and end cover







Using no Loctite® on the nuts, thread them onto the tie-rods by hand, turning clockwise (CW) and without using any washers or lock washers.


Note: do not grease section 'o'-rings!


With all the slices or sections properly aligned between inlet and end cover, start to tighten the nuts starting from the bottom right (1) in a clockwise (CW) manner, going from 20 Nm (15 ft.lb) to 36 Nm (27 ft.lb) and finally to 40 Nm (30ft.lb) using a torque wrench.














How to change an "air cylinder" (slide 1 of 3)



- Start by removing the spool assembly (spool, tang and pneumatic actuator) by loosening the two SHCS (item 4) which normally fasten the pneumatic actuator to the M4 housing.
- Using the clamping tool to clamp the spool, such that it does not rotate, using an allen key (A/K), loosen the pneumatic actuator off of the spool be turning it counter clockwise (CCW) when facing the back port of the pneumatic actuator
- Clean the old Loctite from the end of the spool, spray Loctite cleaner in the .l.D. thread
 of the spool (16) and then, by applying Loctite 222 onto the male thread of the
 pneumatic actuator (6). This is point 3 as found below.
- Note: Sometimes the actuator disassembles between item 6 & 11 as that piece is threaded as well. Should that occur, continue by removing the bonnet which covers the piston (11) by loosening the two SHCS which fastens the bonnet to item 3, the flange.
- Item 6 also has an hex machined in it, hence, using the same allen key, (6) can be removed from the spool (16). Clean the male thread of item 11 and the female thread of 6 and use Loctite cleaner on the threads. Then Loctite using 242 after reassembling.
- With the old pneumatic actuator assembly now removed, the new "air cylinder" can now be installed, provided the spool and housing are still in good working condition.




How to change an "air cylinder" (slide 2 of 3)





INSTALLATION OF PNEUMATIC ACTUATOR:


- 1. ACTUATOR DOES NOT HAVE TO BE DISASSEMBLED TO INSTALL
- 2. INSTALL O-RING 1 INTO FACE GROOVE OF ALUMINUM ADAPTER PLATE 3 (USE A SMALL AMOUNT OF GREASE TO ASSIST O-RING RETENTION)
- 3. APPLY A REMOVABLE GRADE OF "LOCTITE" $\stackrel{\frown}{10}$ TO THREADED ID PORTION OF VALVE SPOOL (M12 x 1)
- 4. WHILE KEEPING O-RING RETAINED IN ADAPTER PLATE, ATTACH ACTUATOR ASS'Y ON TO VALVE SPOOL BY USING A 3/16" HEX WRENCH ENGAGED IN PISTON (11) HEX POCKET (ACCESSED THROUGH THE 1/8" NPT FITTING PORT IN BACK SIDE OF ACTUATOR ASS'Y), AND THREAD THE STOP (6) INTO VALVE SPOOL,
- 5. HOLD SPOOL FROM ROTATING ON OPPOSING END, TIGHTEN TO ~ 10-12 FT. LBS
- 6. SEAT ACTUATOR ASS'Y AGAINST VALVE FACE, AND ORIENT TO MATCH UP BOLT PATTERN MOUNT ADAPER PLATE TO VALVE FACE WITH (2 EA.) M6 -1 x 16 MM LG. SKT. HD. CAP SCREWS 4, USING A 5MM (3/16") HEX WRENCH TIGHTEN BOLTS TO \sim 6-9 FT. LBS
- 7. TEST FOR PROPER ÁLIGNMENT BY TURNING VALVE SPOOL WITH A 3/16" HEX WRENCH ENGAGED IN PISTON (11), VALVE SPOOL SHOULD ROTATE FREELY
- 8. INSTALL FITTINGS AND AIRLINES, TEST FOR PROPER OPERATION















C-S: M4-12-2X centering springs M4-12-2X Main spool centering springs (one on each end of spool) – two types: Light 6-18 bar used with on/off and proportional coils (colour-coded yellow) Heavy 6-30 bar for hydraulic actuation (colour-coded red). Remember the spring collar.



M4 valve diagnostics: Pilot valves can be monitored for an input signal

Test Leads to measure current R987376502

Test Leads to measure voltage R987384170





C-S: M4 valve diagnostics: Pilot valves can be manually overridden


- on/off and proportional coils have a manual override located in the middle of the connector.
- An 2 mm Allen Key will do the trick! Don't be rough with it, and do not use a sharp object such as a screw driver, as scoring can cause leakage across the 'o'-ring!






Ohmic Resistance of coil	s (at 68 °F)
12 VDC On/Off (blue)	10 Ω
12 VDC proportional (black)	2.4Ω







M4 valve diagnostics: reading on an 'MA'-port (LS pressure) of a valve slice






C-S: M4 valve diagnostics: one way of carefully bleeding air out of a function





C-S: M4 valve diagnostics

- Please always check the number of shims and spring orientation!
- Depending on the flow requirement for that slice, either 2x shims, 1x shim or no shims (spacer rings) are required. Spacer ring material # is R900889721
- M6 thread machined in the pressure compensator spool for easy removal of spool out of M4 housing.







rexroth
A Bosch Company

C-S: M4-12 valve symmetrical spools E-H or H actuated symmetrical spools

			spool m	naterial #	
	Q (I/min)	Q (USGPM)	cylinder 'E'	motor 'J'	# of shims
р		*			
۲	005-005	1.25			0
i	006-006	1.5	R901094304	R901108579	1
	007-007	2			2
1	010-010	2.5			0
	012-012	3	R901039175	R901039167	1
0	014-014	3.7			2
t	017-017	4.5			0
٠.	020-020	5	R901039173	R901039166	1
	023-023	6			2
	026-026	7			0
	030-030	8	R901039172	R901039165	1
0	034-034	9			2
n	038-038	10	R901039171		0
р	045-045	12		R901039163	1
e	052-052	13			2
-	057-057	15			0
r	065-065	16	R901039169	R901039162	1
	073-073	20			2
a	070-070	18			0
t	085-085	22	R901039168	R901039161	1
t .	100-100	26			2
e	110-110	29			0
•	120-120	31	R901107414	R901107723	1
d	130-130	33		l	2

* Conventional flow rat	е
-------------------------	---

pneumatically or mechanically actuated symmetrical spools

	aterial #			
# of shims	motor 'J'	cylinder 'E'	Q (USGPM)	Q (I/min)
0			1.25	005-005
1			1.5	006-006
2			2	007-007
0			2.5	010-010
1	R901130112	R901199354	3	012-012
2			3.7	014-014
0		R901205456	4.5	017-017
1	R901205459		5	020-020
2			6	023-023
0			7	026-026
1	R901205477	R901199375	8	030-030
2			9	034-034
0		R901199364	10	038-038
1	R901199368		12	045-045
2			13	052-052
0			15	057-057
1	R901199356	R901199371	16	065-065
2			20	073-073
0			18	070-070
1	R901205480	R901199373	22	085-085
2			26	100-100
0			29	110-110
1	R901199411	R901199410	31	120-120
2			33	130-130



C-S: M4-12 valve spool's material

'A'-side



'B'-side




1039165B39/17 is what is etched on the spool

This makes it an R901039165 spool which from the previous table means that it is an motor spool for an electro-hydraulically actuated slice with a nominal flow rate of 8 USGPM with one shim, often used for a spinner or pre-wet slice.

The 'B' is the internal revision number.

The 39/17 is the date of manufacture, indicating the calendar week and the year





M4 Trouble Shooting - The goal is not to open the control block Electro-hydraulic section will not function: Load sense relief valves are not functioning: Internal pilot pressure is higher than 40 bar: Electro-hydraulic section will not function: No pilot pressure, check pressure at 'X'-port, or now also the 'X1'-port on the lateral or mid-inlet. Electro-hydraulic section will not function: Check electrical supply Try manual over-ride at the FT pilot valve Faulty FT pilot valve cartridge Remember: 12 & 24VDC versions are available!

rexroth
A Bosch Company

M4 Trouble Shooting - The goal is not to open the control block


- Electro-hydraulic section:
 - Spool shifts no response:
- Check system pressure (including main relief; sometimes more than one main relief valve in the system)
- For Open Centre Inlet, unloading inlets minimum is 8 bar
- For Closed Centre Inlet, minimum is 15 bar, recommended 25 bar (360 psi)
- Load sense relief valves are backed out
- Check Load Sense pressure at lateral inlet 'GLS'-port, or mid-inlet 'LS5'-port when shifting the spool
- Pressure Compensator spool stuck in valve slice
- Unloading compensator spool stuck (for Open Centre Inlets)
- Load sense shuttle valve blocked or LS passage plugged (including hose)





M4 Trouble Shooting - The goal is not to open the control block


- High pressure in neutral position:
- Check main spool centering
- Load sense pressure is blocked, not bleeding to tank (remember that the LS signal is a daisy chain function, where multiple shuttle valves ('OR' Gates) are plumbed together in sequence).

































































C-S: M4-12 troubleshooting – high pressure in neutral; LS pressure signal is blocked & cannot bleed away



-----Original Message-----

From:

Sent: April 11, 2018 11:59 AM

To: Richard


Cc: Kevin; de Waard Franklin


Subject: RE: Stuck spool Importance: High


Hi Richard,

Just a heads up , we [are] still having trouble with this unit . not able to stay in stand by .













LATT or LUTT (or LA or LU) end covers				C-S power beyond end covers (S1 or S2)			
slices	L dimension	material #	material description	L dimension	material #	material description	slices
1	90 mm	R900023339	DIN835-M10X90-8.8	140 mm	R900023697	DIN835-M10X140-8.8	1
2	140 mm	R900023697	DIN835-M10X140-8.8	180 mm	R900023640	DIN835-M10X180-8.8	2
3	180 mm	R900023640	DIN835-M10X180-8.8	230 mm	R900023007	DIN835-M10X230-8.8	3
4	230 mm	R900023007	DIN835-M10X230-8.8	270 mm	R900017426	DIN835-M10X270-8.8	4
5	270 mm	R900017426	DIN835-M10X270-8.8	320 mm	R900017427	DIN835-M10X320-8.8	5
6	320 mm	R900017427	DIN835-M10X320-8.8	365 mm	R900076402	DIN835-M10X365-8.8	6
7	365 mm	R900076402	DIN835-M10X365-8.8	420 mm	R900076404	DIN835-M10X420-8.8	7
8	420 mm	R900076404	DIN835-M10X420-8.8	470 mm	R900075187	DIN835-M10X470-8.8	8
9	470 mm	R900075187	DIN835-M10X470-8.8	520 mm	R900076403	DIN835-M10X520-8.8	9 *
10	520 mm	R900076403	DIN835-M10X520-8.8	570 mm	R987379642	not an DIN stud	10 **
CS-M4-12	-2X/STUD-M10	X500-8.8 such t	er beyond in an CS-VEN-l hat the valve will fit the en			87379643 e R900076403 factory tie	rod)
note: no	ot for new proje	cts				70	

















C-S: servicing the hydraulic reservoir





	After the first 100 working hours	After 3 months or 500 working hours	Once every 6 months	Once every 12 months
return filter	replace filter element	replace filter element	replace filter element	
air breather			replace air breather cap assembly	
reservoir	check magnet for ferrous material	check magnet for ferrous material	check magnet for ferrous material	Physically clean the inside







